

Hardness assurance methodology for analog single event transients

Ron Pease, RLP Research, Los Lunas, NM 87031

**Lloyd Massengill, Younes Boulghassoul and Andrew Sternberg,
Vanderbilt University, Nashville, TN 37235**

Stephen Buchner, QSS, Seabrook, MD 20706

Christain Poivey, NASA GSFC, Greenbelt, MD 20771

Dale McMorro, NRL, Washington DC 20375

Mark Savage, NAVSEA Crane, Crane IN 47522

HEART 2004

Monterey, CA

March 4, 2004

Abstract

A methodology is presented for quantifying the effect of SETs in bipolar linear microcircuits on the response of modules or sub-systems where they are used. The methodology follows the format of the piece-part hardness assurance approach described in MIL-HDBK-814.

Outline

- Motivation
- Background
- MIL-HDBK-814 methodology
- Modification for ASETs
- ASET HA flow
- Conclusions


Motivation

Analog single event transients (ASET) in bipolar linear circuits from heavy ion (HI) strikes can cause failure in space systems. A methodology is needed to address piece-part hardness assurance for this effect. The DTRA ASET program has developed a methodology which is presented here.

Background

- ASETs have been studied and characterized since 1993 (Koga, et al TNS 93)
- Many bipolar linear circuits are susceptible to ASETs as presented in a data compendium (Savage, et al IEEE NSREC Data Workshop 01)
- The DTRA ASET program has performed detailed investigations of the mechanisms of ASETs using extensive circuit simulations and heavy ion accelerator, micro-beam and laser testing
- A hardness assurance methodology for ASETs was presented by Marec, et al at RADECS 01
- A generic piece-part hardness assurance methodology was developed by DTRA in the 1980s through the SPWG and is detailed in Military Handbooks
- With minor modifications this methodology can be used for space system piece-parts including parts susceptible to ASETs


Ronan Marec, et al
RADECS 2001



Marec, et al method

- Approach uses a combination of worst case analysis and laser tests if HI data not available for specific application
- Worst case analysis based on maximum amplitude and pulse width of SET observed for different categories of part types
 - Rail to rail voltage amplitude
 - 10 μ s max PW for comparators
 - 20 μ s max PW for op amps
- 80-90 % of cases eliminated on basis of worst case analysis
- Recent data have shown that the maximum SET pulse width can far exceed to values used by Marec, et al invalidating this worst case analysis
 - OP293- up to 500 μ s (Ladbury and Kim, NASA report 02)
 - RH1014- up to 280 μ s (Larsson, et al RADECS 03)

Piece-part HA flow from MIL-HDBK-814



Categorization


- Categorization based on radiation design margin- RDM
- RDM normally defined as mean radiation failure level of part divided by system radiation specification level
- Categories
 - Hardness non-critical (HNC)- no further tests or analysis
 - Hardness Critical Category (HCC)
 - HCC1-lot sample testing required
 - HCC2- periodic lot sample testing (does not apply to space systems)
 - Not acceptable- RDM must increase before part can be used
- Two methods for determining in which category a part is placed based on value of RDM
 - Design Margin breakpoint method- DMBP
 - Part Categorization Criterion- PCC

RDM for ASETs

- For ASETs the normal definition of RDM is not useful
- The definition of RDM proposed for ASETs is the ratio of maximum allowable error rate (specified by SPO) to mean part type error rate for system application and mission environment
- The system specified maximum allowable error rate requires a probability of survival, P_s , and a confidence level, C (often 0.9)
- The following information is required to determine the ASET RDM for a part
 - Definition of failure- minimum amplitude and pulse width of SET that would cause failure for the system application of the part
 - SET cross section vs LET for SET failure pulses
 - System mission parameters
 - Equivalent shielding between part and free field environment
 - Computer code to calculate error rate from mission parameters, device data and effective shielding


Example of failure definition (Boulghassoul, et al RADECS 03)

- Circuit for monitoring the power distribution in a satellite
- Bipolar circuits are LM124 and OP27-1 for current limiters and OP27-2 for current sensor
- Micro-models used to generate SET pulses and macro-models used for other circuits
- Failure occurs if transient at output 1 or 2 exceeds 1.25 V for 6 μ s



ASET Data analysis

- SET cross sections vs. LET are mapped according to peak amplitude and pulse width
- Example shows contours for pulse amplitude
- Integrated with pulse width contour to determine failure σ vs. LET



Error rate calculations

- cosmic ray environment calculated with CRÈME
- integral LET spectrum (Z=1 to Z=92)
- interplanetary weather index M=3
- SET rate calculation using Weibull fit and PROFIT

orbit	km	inclination	without criteria 1 event/X year	with criteria 1 event/X year
LEO	1400	84.7°	X= 15.6	X= 632
MEO	23600	0°	X= 34.6	X= 240
GEO	36000	56	X= 29.2	X= 191.7

HI data vs. laser data

- The laser has been shown to be a very effective tool for identifying the various SET waveforms that can be generated in a circuit
- If there are no HI data then the laser can be used to establish the worst case SET waveforms
- If the worst case SETs are below the failure SET then the part is HNC
- If the worst case SETs meet the failure criterion then HI data are required to establish the σ vs. LET response

Circuit simulations

- The DTRA ASET program has shown that SPICE circuit simulations can be used to accurately generate the SET response
- Very detailed circuit models (micro-models) are required and they must be validated with laser and HI data
- Validated SPICE micro-models can be used to explore worst case bias conditions and to generate SET waveforms for determining failure criteria of the application circuit
- SPICE macro-models can be used for determining the application circuit response for circuits not generating the SET

Categorization

- Design margin breakpoint- DMBP

- Fixed breakpoints
- Used for systems with moderate requirements

$RDM < 2$	$2 \leq RDM \leq 10(?)$	$10(?) < RDM$
Unacceptable	HCC	HNC

- Part Categorization Criteria- PCC

- Based on statistics
- Parametric distribution usually assumed (often lognormal)

$RDM < 2$	$2 \leq RDM \leq PCC$	$PCC < RDM$
Unacceptable	HCC	HNC

- Sample must be representative of flight parts

$$PCC = \exp[KTL * \ln(ER)]$$

KTL one sided tolerance factor
 $\ln(ER)$ - sample standard deviation
of the ln of the error rates

Unacceptable parts

- Substitute a different part type or the same part from a different manufacturer
- Increase the RDM
 - Re-evaluate shielding
 - Re-measure part with less conservative test conditions
 - Re-design application circuit to relax failure criterion
 - Reconsider maximum allowable error rate

Lot sample tests


- All HCC parts must be given a radiation lot sample test (RLAT)
- There are two test methods for RLAT
 - Attributes- go/no-go test
 - Variables data
- Variables data test is required for ASET since an error rate must be determined

Example RLAT test

- Assume max ER is 1/100 years for $P_s=0.999$ and $C=0.9$
- Assume that failure criteria is 1.25V for 6 μ s
- Assume part is OP27, 5 samples, and data have been fit to a Weibull curve. ER has been calculated using the mission parameters and effective shielding
- Assume log normal distribution for ER


Sample #	1/ER (years)	ordered 1/ER	n/(N+1)	ln(1/ER)	NORMSINV
1	225	186	0.17	5.23	-0.97
2	210	196	0.33	5.28	-0.43
3	196	210	0.50	5.35	0.00
4	186	225	0.67	5.42	0.43
5	241	241	0.83	5.48	0.97
			mean	5.35	
			stdev	0.10	
			K_{TL}	6.11	

Inverse cumulative prob. of ln(1/ER)



Since $\exp(\text{mean} - \text{stdev} * K_{TL}) = 112$ years, the lot passes

Proposed ASET hardness assurance methodology



Acknowledgements

This work was funded by DTRA under contract N00164-02-D-6599/DO-03. The authors would like to thank Lew Cohn of DTRA for his support.